

Step 1. Place Ice Chest Holder onto fender scuff guard and against the driver side plastic sweater basket panel as shown.

Step 2. Make sure the holder is far enough away from the front seat back for the ice chest lid to open freely.

Step 3. Drill 2 each 5/16" diameter holes through the plastic sweat basket panel using the holes in the ice chest as a guide.

Step 4. Install the fasteners as shown and tighten securely.

Bolt List: 5/16-18 x ¾ hex bolt-1, 5/16-18 x 2 hex bolt-1, 5/16-18 acorn nut-2, 5/16 lock washer-2, 5/16 fender washer-2

10-8182F-02-01

